

Procedure 1002	<b>Brass Reusable Fitting Selection</b>	Revision 0-04
----------------	---	---------------

### **Male and Female Fittings**

1. Determine the hose Inside Diameter (I.D.).
2. Measure the hose Outside Diameter (O.D.) with a Diameter Tape. Reference **Procedure 1101** for instructions on how to use a Dixon Diameter Tape.
3. Determine the thread size needed to connect the fitting.
4. Select the proper fitting from the Brass Reusable Fitting page of the current DPL (Dixon Price List).

Example:      Hose I.D. - 3/8"  
                  Hose O.D. - 11/16"  
                  Thread needed - 1/4" Male NPTF  
                  Coupling - BN32RU68

### **Hose Splicers**

1. Determine the hose Inside Diameter (I.D.).
2. Measure the hose Outside Diameter (O.D.) with a Diameter Tape. Reference **Procedure 1101** for instructions on how to use a Dixon Diameter Tape.
3. Select the proper fitting from the Brass Reusable Fitting page of the current DPL (Dixon Price List).

Example:      Hose I.D. - 3/8"  
                  Hose O.D. - 11/16"  
                  Coupling - 187-0611