

Procedure 2301	Installation of Dixon Menders	Revision 5-04
----------------	--	---------------

Selection:

- 1. Select mender based on hose I.D. See current DPL (Dixon Price List) for restrictions.
- 2. Select the correct style and size of clamp. Refer to Procedure 1000 ("Boss Clamp Selection) or Procedure 1001 (Pre-formed Band Clamp Selection).

Notes:

- 1. If the mender is to repair a damaged section of hose, cut 12" away from each side of the damaged area.
- 2. If the damage was the result of hose rupture due to excessive pressure, extreme temperature or incompatibility between the hose tube and the product being conveyed, replace the hose with one appropriate for the application. Do not use a mender.

Preparation:

- 1. Prepare and mark the hose using Procedure 1100 (General Preparation Instructions).
- 2. Mark the middle of the mender.

Process:

- 1. Insert the mender up to its midpoint into one piece of the hose.
- 2. Place the clamp(s) in its/their proper position.
- 3. Based on the style of clamp and installation method selected, use one of the following:
 - a. Procedure 2100 (Installation of Pre-Formed Band Clamp Using Pneumatic Rollover Tool).
 - b. Procedure 2101 (Installation of Pre-Formed Band Clamp Using Punch Style Tool).
 - c. Procedure 2103 (Installation of Pre-Formed Band Clamp Using Screw-Action Tool with Rollover Tool Attachment).
 - d. Procedure 2104 (Installation of "Clamp-It" Band and Buckle Using Screw Action Tool).
 - e. Procedure 2201 (Installation of Double Bolt Clamps (with saddles)).
- 4. Insert the other end of the mender into the other piece of hose. Hose ends should make contact. **Note:** If pre-formed band clamps are used, they must be slid over the hose ends before the mender is inserted.
- 5. Place the clamp(s) in its/their proper position.
- 6. Install clamp(s) using same procedure as used in Step 3.
- 7. Check work using Procedure 3000 (Criteria for Sufficient fit of Boss Clamp), 3001 (Bolt Clamp Inspection) or 3002 (Band clamp Inspection).
- 8. Test assembly using Procedure 4000 (General Hydrostatic Testing Information) and 4001 (Hydrostatic Testing).

Assembled By: _____ Tested By: _____ Reference No. _____
 Assembled Date: _____ Test Date: _____